ROBUS®

INSTRUCTION MANUAL

OHIO 12W IP54 CIRCULAR BULKHEAD, 3000K/4000K, C/W WHITE AND BLACK TRIMS

RHC1230-01, RHC1240-01

PLEASE READ INSTRUCTION BEFORE COMMENCING INSTALLATION AND RETAIN FOR FUTURE REFERENCES.

! Electrical products can cause death or injury, or damage to property. If in any doubt about the installation or use of this product, consult a competent electrician Note:


Product technical information and specification may change over time without prior notification. For the latest technical information please visit our web site www.ledgrouprobus.com.au


-20°C < Ta < +40°C, 220-240V~50/60Hz, Class II, IP54


Luminaire is non-dimmable Suitable for mounting on a normally flammable surface.


Installation


- 1. Ensure mains supply is switched off before commencing work
- 2. Choose suitable location for mounting the fitting
- 3. Ensure there is at least 100mm of free space around the fitting location
- 4. Using a flat head screw driver remove the trim. Expose the base by removing the screws. Remove diffuser/ LEDs from base. Unplug connector
- 5. Drill mounting holes in the base
- 6. Mark appropriate fixing hole positions on wall, check location of buried cables, pipes and other building services before drilling.
- 7. Feed supply cables through cable entry hole and attach base to surface
- 8. Connect supply to terminals Brown to L and Blue to N
- 9. Plug in connector, attach diffuser/ LEDs and tighten screws. Ensure that it is secure. Attach appropriate base











The Installation must be carried out by a qualified electrician

LED Group Australasia 9/210 Queensport Road North Murarrie QLD 4172 Australia





lssue 1 080816